

# Human Dengue Virus IgG (DV-IgG) ELISA Cat No: K12-S2152

## Principle:

This is enzyme-linked immunosorbent assay (ELISA) to assay the level of Human Dengue Virus IgG in samples. Addition of controls or sample to Microtitre well which is pre-coated with Human Dengue Virus IgG Anti -human monoclonal antibody, if Human Dengue Virus IgG present, it will bind to the Human Dengue Virus IgG monoclonal anti-human antibody coated on plate during incubation. After washing addition of HRP conjugate to form immune complex. Unbound HRP conjugate will get removed by washing step after incubation. Then addition of Substrate A and B, develops blue color during incubation period and reaction will get stop after addition of stop solution with development of yellow color. The concentration of the Human Dengue Virus IgG of sample is directly proportional to the yellow color developed in well and will be positively correlated.

#### Intended Use:

The Kit is used to assay the level of Human Dengue Virus IgG in human serum and plasma samples. The Kit is For Laboratory / Research Use Only.

#### Materials provided in the kit:

- 1. Anti-Human Dengue Virus IgG Coated Microtitre Coated Plate (96 wells) 1 no
- 2. Positive Control 0.5 ml
- 3. Negative Control 0.5 ml
- 4. HRP Conjugate 6 ml
- 5. Sample diluent 6 ml
- 6. (30X) Wash Buffer 20 ml
- 7. Substrate A 6 ml
- 8. Substrate B 6 ml
- 9. Stop Solution 6 ml
- 10. Instruction Manual

# Materials to be provided by the End-User:

- 1. Microplate Reader able to measure absorbance at 450 nm.
- 2. Adjustable pipettes to measure volumes ranging from 50 ul to 1000 ul.
- 3. Deionized (DI) water.
- 4. Wash bottle or automated microplate washer.
- 5. Graph paper or software for data analysis.
- 6. Tubes to prepare standard/sample dilutions.
- 7. Timer.
- 8. Absorbent paper.
- 9. Incubator

### **Storage Information:**

- 1. All reagents should be stored at 2°C to 8°C.
- 2. All the reagents and wash solutions are stable until the expiration date of the kit.
- 3. 30 minutes prior before use, bring all components to room temperature (18-25°C). Store all the components of the kit at its appropriate storage condition after use.
- 4. The Substrate is light-sensitive and should be protected from direct sunlight or UV sources.

# **Health Hazard Warnings:**

- 1. Reagents that contain preservatives may be harmful if ingested, inhaled or absorbed through the skin. Refer to the MSDS online for details.
- 2. To reduce the likelihood of blood-borne transmission of infectious agents, handle all samples in accordance with NCCLS regulations.

# **Specimen Collection and Handling:**

Specimens should be clear and non-hemolyzed. Samples should be run at a number of dilutions to ensure accurate quantitation.

1. The kit cannot test samples which contain NaN3, because NaN3 inhibits HRP activity.



- 2. Extract as soon as possible after specimen collection as per relevant procedure. The samples should be tested as soon as possible after the extraction. Alternately the extracted samples can be kept in -20°C. Avoid repeated freeze-thaw cycles.
- 3. **Serum-** Coagulate at room temperature for 10-20 minutes; centrifuge for 20-min at 2000-3000 rpm. Remove the supernatant. If precipitation appears, recentrifuge.
- 4. **Plasma-** Use EDTA or citrate plasma as an anticoagulant, mix for 10-20 minutes; centrifuge for 20-min at the 2000-3000 rpm. Remove the supernatant. If precipitation appears, re-centrifuge.

**Note:** Grossly hemolyzed samples are not suitable for use in this assay.

#### Reagent Preparation (all reagents should be diluted immediately prior to use):

- 1. Bring all reagents to Room Temperature prior to use.
- 2. To make 1X Wash Solution, add 13.33 ml of 30X Wash Buffer in 386.67 ml of DI water.

#### **Procedural Notes:**

- 1. In order to achieve good assay reproducibility and sensitivity, proper washing of the plates to remove excess un-reacted reagents is essential.
- 2. High Dose Hook Effect may be observed in samples with very high concentrations of Human Dengue Virus IgG. High Dose Hook Effect is due to excess of antibody for very high concentrations of Human Dengue Virus IgG present in the sample. High Dose Hook effect is most likely encountered from samples early in the purification process. If Hook Effect is possible, the samples to be assayed should be diluted with a compatible diluent. Thus if the Human Dengue Virus IgG concentration of the undiluted sample is less than the diluted sample, this may be indicative of the Hook Effect.
- 3. Avoid assay of Samples containing Sodium Azide (NaN<sub>3</sub>), as it could destroy the HRP activity resulting in under-estimation of the amount of Human Dengue Virus IgG.
- 4. It is recommended that all Controls and Samples be assayed in duplicates.
- 5. Maintain a repetitive timing sequence from well to well for all the steps to ensure that the incubation timings are same for each well.
- 6. If the Substrate has a distinct blue color prior to use it may have been contaminated and use of such substrate can lead to poor sensitivity of the assay.
- 7. The plates should be read within 30 minutes after adding the Stop Solution.
- 8. Make a work list in order to identify the location of Controls and Samples.

#### **Assay Procedure:**

- 1. Bring all reagents to room temperature prior to use. It is strongly recommended that the Positive Control be run in duplicate or triplicate.
- 2. Add 40 ul of Sample Diluent in test wells.
- 3. Add 10 ul of Sample in test wells. Use the pipette to mix the samples properly in each well.
- 4. Add 50 ul of Negative Control in the negative control well.
- 5. Add **50 ul** of **Positive Control** in the positive control well.
- 6. Shake the plate gently for 30 seconds to mix the reagents in the wells. Care should be taken to avoid any spillage.
- 7. Incubate at 37 °C for 30 minutes.
- 8. Aspirate and wash plate 5 times with 300 µl **Wash Buffer (1x)** and blot residual buffer by firmly tapping plate upside down on an absorbent paper. Wipe off any liquid from the bottom outside of the Microtitre wells as any residue can interfere in the reading step. All the washes should be performed similarly.
- 9. Add **50 ul** of **HRP Conjugate** to each well. (Do not add into blank control well)
- 10. Incubate at 37 °C for 30 minutes.
- 11. Aspirate and wash plate 5 times with 300 µl **Wash Buffer (1x)** and blot residual buffer by firmly tapping plate upside down on an absorbent paper. Wipe off any liquid from the bottom outside of the Microtitre wells as any residue can interfere in the reading step. All the washes should be performed similarly.
- 12. Add 50 ul of Substrate A into all wells.
- 13. Add 50 ul of Substrate B into all wells.
- 14. Incubate at 37 °C for 10 minutes.
- 15. Add 50 ul of Stop Solution into all wells. (Do not add into blank control well)
- 16. Calibrate the plate reader with blank control well and read the plate using microwell plate reader at 450 nm

#### **Precautions:**

Do not mix reagents from different kits or lots. Reagents and/or antibodies from different manufacturers should not be used with this set.



#### **Performance Characteristics:**

Please note that this validation is performed in our laboratory and will not necessarily be duplicated in your laboratory. This data has been generated to enable the user to get a preview of the assay and the characteristics of the kit and is generic in nature. We recommend that the user performs at the minimum; the spike and recovery assay and the dilutional linearity assay to assure quality results. For a more comprehensive validation, the user may run the protocols as suggested by us herein below to develop the parameters for quality control to be used with the kit.

#### Specificity:

The antibodies used in the kit for capture and detection are specific for Human Dengue Virus IgG.

#### Interpretation of Results:

- It is recommended that each laboratory establish their own criteria for performance of these Research Reagents.
- 2. In our quality control testing, we use the following criteria:

#### **Reference Value:**

Negative Control  $\leq 0.10$ Positive Control  $\geq 1.00$ 

The critical value (CUT OFF) calculation: critical value = the average value of negative control + 0.15

Negative judgment: if the OD value< CUT OFF, the sample is Human DV-IgG negative.

Positive judgment: if the OD value ≥CUT OFF, the sample is Human DV-IgG positive.

#### LIMITED WARRANTY

KinesisDx does not warrant against damages or defects arising in shipping or handling, or out of accident or improper or abnormal use of the product; against defects in products or components not manufactured by KinesisDx, or against damages resulting from such non-KinesisDx made products or components. KinesisDx passes on to customer the warranty it received (if any) from the maker thereof of such non-Krishgen made products or components. This warranty also does not apply to product to which changes or modifications have been made or attempted by persons other than pursuant to written authorization by KinesisDx.

THIS WARRANTY IS EXCLUSIVE. The sole and exclusive obligation of KinesisDx shall be to repair or replace the defective product in the manner and for the period provided above. KinesisDx shall not have any other obligation with respect to the products or any part thereof, whether based on contract, tort, strict liability or otherwise. Under no circumstances, whether based on this Limited Warranty or otherwise, shall KinesisDx be liable for incidental, special, or consequential damages.

This Limited Warranty states the entire obligation of KinesisDx with respect to the product. If any part of this Limited Warranty is determined to be void or illegal, the remainder shall remain in full force and effect.

KinesisDx 2020

THANK YOU FOR USING KINESISDX PRODUCT!





# Human Dengue Virus IgG (DV-IgG) ELISA

# **ASSAY PROCEDURE**

1	Bring all reagents to room temperature before use.		
2	Pipette Sample Diluent		40 ul
	Sample	10 ul	
3	Pipette Negative and Positive Control	50ul	
4	Incubate	30 minutes (37°C)	
5	Wash 1X Wash Buffer	Decant, 5 x 300 ul	
6	Pipette HRP Conjugate	50ul	50 ul
7	Incubate	30 minutes (37°C)	
8	Wash 1X Wash Buffer	Decant, 5 x 300 ul	
9	Pipette Substrate (A)	50 ul	50 ul
10	Pipette Substrate (B)	50 ul	50 ul
11	Incubate in the dark	15 minutes (37°C)	
12	Pipette Stop Solution	50 ul	50 ul
13	Measure 450 within 15 mins		



#### Troubleshooting:

#### **Problem** Possible cause Investigation/Actions High Absorbances 1. Cross-contamination from other specimens > Repeat assay taking care when washing and pipetting. 2. Insufficient or inefficient washing or reading Check washer efficiency 3. Wavelength of filter not correct. Check that the wavelength is 450nm. If a dual reference filter between 600-650 nm. Repeat assay and include a well that contains only 4. High assay background. 5. Contaminated TMB Check that TMB is colorless or faint blue. 6. Incubation time too long or incubation Check incubation time and temperature. temperature too high. Check incubator is at the correct temperature. 7. Incorrect dilution of serum Repeat assay, ensuring correct serum dilution is used. Low Absorbances 1. Incubation time too shot or incubation temperature too low. Check incubator is set at the correct temperature. Repeat assay ensuring correct dilutions and volumes are used. 2. Incorrect dilution or pipetting of sera Ensure controls are sufficiently mixed. 3. Incorrect filter wavelength. 600-650nm. 4. Contaminated Conjugate solution. Do not return unused Conjugate to bottle. bleach. 5. Kit has expired. Check expiration date of kit and do not use if expired. 6. Air blank reading high. 7. Incorrect storage of kit. desiccant sachet is blue/purple. Allow sufficient time for reagents to equilibrate to room 8. Kit reagents not equilibrated at room temperature prior to assay. temperature Check the reagents used match those listed on the specification 9. Incorrect reagents used. sheet. 10. Over washing of plate (e.g. inclusion of a long soak step). Poor Duplicates 1. Poor mixing of samples. 2. Poor pipette precision Calibration may need to be checked. 3. Addition of reagents at inconstant timing Use consistent timing when adding reagents. intervals; reagent addition takes too long, air bubbles when adding reagents. improve pipetting technique and skill. 4. Inefficient washing - Wash buffer left in wells, Tap out wash buffer after washing. inconsistent washing, inadequate washing. when washing. 5. Reader not calibrated or warmed up prior to Check reader precision Check reader manual to ascertain warm up time of instrument. plate reading. 6. Optical pathway not clean Gently wipe bottom of plate. Check reader light source and detector are clean. 7. Spillage of liquid from wells Serum samples exhibit microbial growth, haemolysis or lipaemia.

# All wells yellow

- Contaminated TMB.
- Contaminated reagents (e.g. Conjugate, Wash buffer).

9. Uneven well volumes due to evaporation.

- 3. Incorrect dilution of serum.
- 4. Incorrect storage of kit.
- 5. Inefficient washing- Wash buffer left in wells, inconsistent washing, inadequate washing.
- 6. If Conjugate reconstitute is required -Conjugate reconstituted incorrectly.

- wavelength spectrophotometer is available, set the
- sample diluent or sample absorbent (i.e. a blank well).
- Ensure time and temperature of assay incubation are correct.

- Check the wavelength is set at 450nm. If a dual wavelength spectrophotometer is available, set the reference filter between
- Dispense conjugate directly from the bottle using clean pipette tip; avoid transferring Conjugate to another container if possible.
- Ensure all pipettes and probes used to dispense the Conjugates are clean and free from serum, detergent and
- Investigate causes of high background absorbance.
- Ensure kit is stored at 2-8°C, plate is sealed in foil pouch and

- Repeat assay using recommended wash procedure.
- > Mix reagents gently and equilibrate to room temperature.
- Check pupating technique-change pipette tip for each sample and ensure excess liquid is wiped from the outside of the tip.
- Ensure all dilutions are made before commencing addition to
- Check wells are sufficiently and uniformly filled and aspirated

- Repeat assay, taking care not to knock the plate or splash liquid
- It is not recommended to use serum samples exhibiting microbial growth, haemolysis or lipaemia.
- Cover plate with a lid or plate sealer (not provided).
- Check TMB is colorless or faint blue.
- Check reagents for turbidity.
- Repeat assay, ensuring correct serum dilution is used.
- Ensure kit is stored at 2-8°C, plate is sealed in foil pouch and desiccant sachet is blue / purple.
- Tap out wash buffer after washing.
- Check wells are sufficiently and uniformly filled an aspirated when
- Repeat assay ensuring Conjugate is reconstituted according to assay method.



All wells negative

- 1. Test not performed correctly correct reagents not added or not added in the correct sequence.
- 2. Contaminated Conjugate solution.
- 3. Over- washing of plate (e.g. inclusion of a long soak step).
- 4. Incorrect storage of kit.
- 5. Wash Buffer made up with Stop Solution instead of Wash Buffer Concentrate

- > Check procedure and check for unused reagents.
- Ensure that Stop Solution was not added before Conjugate or
- > Ensure that serum was diluted in correct Sample diluent; e.g. do not use Sample Absorbent for an IgG ELISA.

  Dispense Conjugate directly from the bottle using a clean pipette
- tip; avoid transferring Conjugate to another container if possible. Do not return unused Conjugate to bottle.
- Ensure all pipettes and probes used to dispense the Conjugate are clean and free from serum, detergent and bleach.
- Repeat assay using recommended wash procedure.
- Ensure kit is stored at 2-8°C, plate is sealed in foil pouch and desiccant sachet is blue / purple.
- > Ensure Wash Buffer is made up correctly.